



TO PLAY THE RECORD;

USE THE LEVER TO THE RIGHT OF THE TONE-ARM TO LIFT THE STYLUS.

MOVE THE TONE-ARM SIDEWAYS TO THE TRACK THAT YOU WANT TO PLAY.

GENTLY LOWER THE STYLUS ONTO THE RECORD USING THE LEVER.

ALWAYS USE THE LEVER TO MOVE THE STYLUS TO A DIFFERENT TRACK.

TO PLAY THE OTHER SIDE OF THE RECORD;

MOVE THE TONE-ARM BACK TO ITS RESTING POINT ON THE RIGHT HAND SIDE.

WAIT FOR THE RECORD TO STOP SPINNING (FOR SOME OF THE TURNTABLES

YOU WILL NEED TO PRESS THE PLAY BUTTON.

USING BOTH HANDS, LIFT THE RECORD BY THE EDGES, TURN OVER AND

PLACE CAREFULLY ON THE TURNTABLE.

PLEASE

NO SCRATCHING.

SLOWING DOWN THE SPEED OF THE TURNTABLE WITH YOUR HAND

CHANGING THE OUTPUT LEVELS ON THE MIXER